



LAMBDA PRECIFLOW

Peristaltic Pump - Tubing Pump

OPERATION MANUAL



LAMBDA Laboratory Instruments

Dr. Pavel Lehky
Imfeldsteig 12
CH - 8037 Zurich
Switzerland
Tel/Fax: +41 44 450 20 71

LAMBDA CZ s.r.o.

Lozibky 1
CZ - 614 00 Brno
Czech Republic
Tel/Fax: +420 545 578 643
Hotline: +420 603 274 677

www.lambda-instruments.com

LAMBDA PRECIFLOW peristaltic pump – tubing pump

The LAMBDA peristaltic pumps have been developed for continuous cultures as the result of over twenty years of laboratory experience and involved the systematic elimination of the imperfections found in other pumps on the market.

The result is a practical, precise and reliable pump - the most compact in its class.

- Flow rates from 0.01 to 600 ml/hour
- Large digital speed setting range from 0 to 999
- Greatly extended tubing life and decreased pulsation
- Extensive remote controls
- Very economic in use
- Virtually noiseless operation
- Tubing economy pays the pump after the use of mere 80 m tubing!
- Access to reaction kinetics by using the pump-flow INTEGRATOR
- Low voltage plug-in power supply for maximum safety
- RS-485 interface (optional)
- Control software PNet (optional)

LAMBDA Laboratory Instruments

is developer and producer of special laboratory instruments mainly for biotechnology, microbiology, food and agricultural, chemical and pharmaceutical research and development, educational use as well as for general laboratory and research applications.

LAMBDA MINIFOR - innovative and compact laboratory fermenter / bioreactor

LAMBDA OMNICOLL - fraction collector with new concept for unlimited number of fractions

LAMBDA PRECIFLOW, MULTIFLOW, HIFLOW and MAXIFLOW peristaltic pumps - practical, precise and extremely compact

LAMBDA SAFETY POWDER DOSER - allows automatic addition of powder without spoon. Safe operation with hazardous material (GLP)

LAMBDA VIT-FIT polyvalent syringe pump with extremely robust mechanics - programmable infusion and filling from micro syringes to large volume syringes of 150 ml without adapter

LAMBDA MASSFLOW is a precise and programmable gas flow controller

LAMBDA PUMP-FLOW INTEGRATOR - with LAMBDA pumps and doser allows the visualization and recording of the pumped volume

TABLE OF CONTENTS

1.	SETTING UP THE PERISTALTIC PUMP	3
1.1	Insertion of the tubing	3
1.2	ON/OFF button	4
1.3	Setting of the flow rate	4
1.4	Setting of the flow direction.....	4
1.5	Fast filling or emptying of the line	4
2.	REMOTE CONTROLS	5
2.1	ON/OFF remote control	5
2.2	Remote control of the pump speed.....	5
2.3	PC control	5
3.	RECOMMENDATIONS	6
4.	FOR YOUR SAFETY	6
5.	CONSTRUCTION ADVANTAGES OF THE PRECIFLOW PUMP	6
6.	ACCESSORIES AND SPARE PARTS	7
6.1	Pump-Flow Integrator (Art. no. 4803)	7
6.2	List of accessories and spare parts	8
7.	FLOW RATE DIAGRAM	9
8.	UTILIZATION OF THE LAMBDA PERISTALTIC PUMPS	10
9.	TECHNICAL SPECIFICATIONS	11
9.1	General specifications	11
9.2	Remote control (Inputs/Outputs).....	12
9.3	Input (12 V DC).....	12
10.	GUARANTEE	13
11.	APPENDIX	14
11.1	RS-485 communication protocol for LAMBDA VIT-FIT, PRECIFLOW, MULTIFLOW, HIFLOW and MAXIFLOW pumps	14
11.2	Examples	15
11.3	How to set the pump address	15
11.4	RS-connection scheme.....	15

OPERATING INSTRUCTIONS

1. SETTING UP THE PERISTALTIC PUMP

1.1 Insertion of the tubing

- Plug the connector of the power supply into the corresponding socket at the back side of the peristaltic pump and secure it in place by rotation of the ring.
- Plug the power supply into the AC mains (230V/50-60 Hz). After a short beep signal the display will be illuminated. The last used settings will be displayed.
- Remove the clear PVC cover by rotating it to the left or to the right (figure 1). A short video of the installation is on: <http://www.lambda-instruments.com/?pages=video>
- Press the **ON/OFF** button and select the sense of rotation of the pump by pressing the button **◀|▶**, so that the rotor will turn in a clockwise direction.
- Set the pump speed to about 500 (sense of rotation **▶**) by pressing the corresponding buttons **▲▲▲** under the LED display.
- Press the tubing into the back slot on the top of the peristaltic pump. Thin tubing should be pushed completely to the bottom of the slot. Guide the tubing around the outside of the slowly turning plastic bearing towards the front slot (figure 2). Then press the tubing into the front slot to secure it (figure 3).
- Replace the transparent cover by placing it again on the top of the pump and turn it so that the steel ball embedded in the left-front corner fits into the corresponding notch in the PVC cover. When the cover is gently pressed, the bearings will automatically adjust themselves.




Fig. 1: Removing the cover



Fig. 2: Insertion of the tubing



Fig. 3: Tubing in the pump head

1.2 ON/OFF button

By pressing the **ON/OFF** button the pump is switched on or off. The internal memory will show the last used speed and flow direction setting.

1.3 Setting of the flow rate

The flow rates delivered by peristaltic pumps depend on the internal diameter of the tubing and the pump rotation speed. The speed of rotation can be selected by the control buttons **▲ ▲ ▲** under the LED display.

The PRECIFLOW tubing pump has been constructed for tubing with an internal diameter ranging from 0.5 to 4 mm with a tubing wall thickness of approximately 1 mm. The best results have been obtained with silicon tubing, but tubing made from other materials with similar elasticity can also be used.

The volume of liquid pumped per hour for tubing of different diameter and different speed settings is shown in the flow rate diagram in section 7. The flow rates of the LAMBDA PRECIFLOW peristaltic pump can be varied over a large range from 0.01 to 600 ml/hour.

With the control buttons **▲ ▲ ▲** below the LED display the motor speed is selected. The speed setting from 0 to 999 corresponds to the velocity of the movement of the motor. The best way to correlate the flow rate obtained with the respective tubing is to make a preliminary calibration, in which the pump is allowed to pump the liquid over a certain time with a selected speed setting (e.g. for 1 minute with speed setting 500). Then, the weight or volume of the pumped sample is measured. Using this information the speed setting corresponding to the desired flow rate can be calculated easily (rule of three).

1.4 Setting of the flow direction

The direction of pump rotation can be selected by the **◀|▶** button. The corresponding direction LED diode will be on.

1.5 Fast filling or emptying of the line

If the direction **◀|▶** button is pressed continuously for about 2 seconds, the pump will rotate at maximum speed in the sense of rotation indicated by the LED. After releasing this button the pump is stopped. This is useful for filling tubing before the start of operation or for emptying tubing at the end of operation. This "HOLD=MAX" function can be used even though the **ON/OFF** button has not been pressed.

2. REMOTE CONTROLS

2.1 ON/OFF remote control

By interlinking the contacts no. 4 and 5 of the socket at the rear of the pump (see figure 4), the pump will be blocked and both direction indicating LEDs will be switched off.

The same effect will be obtained by applying a voltage of 3 to 12 V DC to the contact no. 5 (0 line must be connected to contact no. 3).

Remark: In some cases a reversed logic for the remote control might be desired. Please contact us in this case.



Fig. 4: Backside of the pump

2.2 Remote control of the pump speed

The LAMBDA peristaltic pumps can be controlled over the whole range by an external signal (0 - 10 V, option 0-20 or 4-20 mA). The plus pole of the signal is connected to the contact no.1, 0 line to the contact no.3.

Press the button **REMOTE** on the front panel. The corresponding LED diode will go on and the display will indicate the approximate voltage of the external signal. This indication may become unstable when no external connection is made and indicates the high sensitivity of the electronics.



For safety reasons the voltage of the external signal must **not exceed** 48 V to earth!

2.3 PC control

When the instrument has been equipped with the optional RS-232 or RS-485 interface, it can be controlled digitally, e.g. from a PC.

Disconnect the pump from the mains. While keeping the direction button **◀|▶** pressed connect the pump to the mains again. The message **“A”** and two numbers will appear on the display. This number from 00 to 99 is the current address of the pump. To change the address press the buttons **▲▲▲** under the display until the desired number is obtained. To confirm the address and save it, press the **ON/OFF** button.

3. RECOMMENDATIONS

- It is advisable to use tubing with a small diameter and high-speed control setting for small flow rates rather than the opposite. This allows a finer selection of flow rates.
- If possible use the clockwise rotation of the tubing pump. This results in lower friction and the pressure of the liquid is also lower (approx. 0.1 MPa). If a higher pressure is required (up to 0.15 MPa) use the counter-clockwise rotation.
- Periodically smear a small amount of petroleum jelly or similar grease on the inner side of the transparent PVC cover of the peristaltic pump. This will increase the reliability and the lifetime of your peristaltic pump. **Do not grease the tubing holding slots.**
- If, as a consequence of tubing breakage or some other accident, liquid spills into the top of the tubing pump, disconnect the pump from the mains and clean it by removing the liquid and rinsing it with water. The rotor can be completely removed by unscrewing the nut (size M4) on the axis of the rotor and pulling the rotor out by hand or with pliers. After cleaning, grease the axis and replace the rotor by pressing and rotating until the rotor engages on the motor axis.
- Clean the peristaltic pump with a damp cloth. Mild solvents like ethanol, isopropanol, alkanes are tolerated, if the exposure is short.
- If you have any difficulties or questions concerning your PRECIFLOW peristaltic pump, please contact our service office.

4. FOR YOUR SAFETY

Thanks to the use of a plug-in power supply giving only a low voltage of 12 V DC the danger of electrical shock during the use of the PRECIFLOW peristaltic pump has been virtually eliminated, even when an electro conductive solution penetrates the tubing pump.

The peristaltic pump is usually used in a vertical position. The peristaltic pumps can also be stacked, thus allowing optimal use of your expensive laboratory areas.

If the tubing pump is not used for an extended period of time, disconnect it from the mains. A modern miniaturized switching power supply is used, which has only a negligible consumption of electric current when the peristaltic pump is not in use.

5. CONSTRUCTION ADVANTAGES OF THE PRECIFLOW PUMP

- Instead of small rollers, which are used by most pump producers, LAMBDA peristaltic pumps use ball bearings of a larger diameter with glass beads. This reduces pulsation, friction and mechanical strain on the tubing leading to better pump performance.
- The bearings glide over the tubing so gently, that unlike in other tubing pumps, it is not necessary to prevent the movement of the tubing by any special fixation (stoppers, clamps etc.). As a consequence, the lifetime of the tubing is considerably increased.
- The pressure on the tubing is transmitted gradually through an off-centre lever and spring made of stainless steel. This assures that only minimal pressure is applied to the tubing,

which guarantees reliable functioning of the pump without unnecessary deformation of the tubing.

- The spring also reduces the liquid pressure to approx. 1.5 bar. This is useful when for any reason the line is blocked.
- The asymmetric pump head reduces pulsation and is made from hard, chemically stable material.
- A high quality, Swiss made, stepping motor, together with integrated microprocessor electronics assure highest precision of flow rates with no inertia while turning the peristaltic pump on and off.
- The tubing pump dimensions have been minimized. Therefore the PRECIFLOW peristaltic pump is considerably smaller than other products of similar performance. The pump is easy to use and saves expensive laboratory bench space.
- The different remote control options and the possibility of flow integration increase the scope of use of the LAMBDA peristaltic pumps in automatically controlled systems (e.g. in fermentations and cell cultures, chemical synthesis, fraction collection, etc.)
- The PRECIFLOW peristaltic pump can be equipped with a RS-232 or RS-485 interface (optional) allowing for digital control, e.g. from a PC. This opens the possibility to realize almost any flow rate profile. This is particularly useful when adding medium to a fermentor or bioreactor to feed the culture which is also growing exponentially. Thus, the growth rate and resulting culture activity are considerably increased.

6. ACCESSORIES AND SPARE PARTS

6.1 Pump-Flow Integrator (Art. no. 4803)

The LAMBDA PRECIFLOW peristaltic pump and the other LAMBDA pumps are the only pumps on the market, which allow **a simple and precise integration of the amount of liquid that has been delivered by the pump.**



The electrical impulses, which move the pump motor, are registered and transformed into a direct voltage. This voltage can be measured or recorded by common recorders or voltmeters. The RS 485 interface allows the control from a PC.

In processes where the pump is controlled e.g. by a pH-stat during a fermentation or cell culture to keep the pH of the medium constant, it is often important to know when and how much acid or base were added. **This data yields important information about the process, its kinetics and time of completion, etc.**

Another use of the INTEGRATOR is for the **measurement of enzyme activities** (e.g. amidases, esterases, lactamases, lipases, proteases and other enzymes).

The pump-flow INTEGRATOR can be conveniently placed under the PRECIFLOW peristaltic pump, to which it is connected by a cable to the 8-pole socket at the rear of the pump (figure 4).

The INTEGRATOR connected to LAMBDA peristaltic pumps **allows new and unusual pump applications** (e.g. gradient making, counter flow elution, liquid chromatography, electronic burette, etc.) also shown in section 8.

6.2 List of accessories and spare parts

Art No	Accessories
4803	PUMP-FLOW INTEGRATOR (for LAMBDA pumps, DOSER and MASSFLOW)
4810	Pump remote control (analog and digital) cable (8 poles)
4802	Pump ON/OFF remote control cable (2 poles)
	Interface and Control software
4822	RS232 interface (for connection of the instruments to the serial port)
4816	RS485 interface (for connection of the instruments to the serial port)
4817	RS232/485 converter
4818	Power supply for RS232/485 converter (5V/1W)
4819	RS-line connection cable (serial)
6600	PNet control software for peristaltic and syringe pumps, DOSER or MASSFLOW
800202	Quadruple plug box (Power and RS-connection for up to 4 LAMBDA laboratory instruments)
	Spare parts
4820	Plug-in power supply (12V/6W) for PRECIFLOW, MULTIFLOW, DOSER, MASSFLOW
4804	Adaptor for 230V output controllers
4805	Roller
4806	Stainless steel spring
4807	Eccentric lever
4808	Rotor
4809	Cover
4811	Pump head
4813-s	Stepping motor (PRECIFLOW, MULTIFLOW)
4814-s	Gearbox (PRECIFLOW, MULTIFLOW)
4815	Silicone tubing 3/5mm x 10m
800113	Stainless steel tubing clamp

7. FLOW RATE DIAGRAM

The following figure shows the flow rate diagram of the PRECIFLOW peristaltic pump as a function of pump speed setting and internal tubing diameter. The flow rates are indicative and can differ depending on the pumped substance, pressure, tubing etc.






Fig. 5: Flow rate diagram of the LAMBDA PRECIFLOW peristaltic pump

8. UTILIZATION OF THE LAMBDA PERISTALTIC PUMPS



9. TECHNICAL SPECIFICATIONS

9.1 General specifications

Type:	LAMBDA PRECIFLOW – microprocessor-controlled peristaltic pump
Accuracy:	± 1%
Reproducibility:	± 0.2 % (electronics)
Tubing:	Silicone tubing or other materials having similar elasticity; inner tubing diameter from 0.5 to 4 mm and tubing wall thickness of approx. 1 mm
Flow rate range:	
Minimum:	0.01 ml/hour with 0.5 mm inner tubing diameter
Maximum:	600 ml/hour with 4 mm inner tubing diameter
Non-volatile memory:	storage of all settings
Maximum pressure:	approx. 0.1 MPa in clockwise rotation; approx. 0.15 MPa in counter-clockwise rotation
Motor:	microprocessor controlled stepping motor
Speed control range:	0 to 999
Interface:	RS-485 (optional)
Power supply:	95–240 V/60–50 Hz AC plug-in power supply with DC 12V/6W output; possible field operation on 12 V accumulator
Dimensions:	10.5 (W) x 9.5 (H) x 10.5 (D) cm
Weight:	1.2 kg
Safety:	CE, meets IEC 1010/1 norm for laboratory instruments
Operation temperature:	0-40 °C
Operation humidity:	0-90% RH, not condensing
Remote control:	0-10 V; (option 0-20 or 4-20 mA)




For safety reasons the voltage of the external signal must **not exceed** 48 V to earth!

9.2 Remote control (Inputs/Outputs)

No.	Color	Description
1	yellow	(+) input remote speed control 0-10V *)
2	grey	step signal from stepping motor (0 and 12V)
3	green	earth, 0 V
4	brown	+ 12 V
5	white	(+) input remote ON/OFF; 0V = ON, 3-12 V = OFF (this logic can be inversed on demand)
6	pink	earth, ground (GND)
7	red	RS 485 B (-)
8	blue	RS 485 A (+)


*) (zero line connected to the contact no. 3)



8-pole connector

9.3 Input (12 V DC)

Contact No.	Description
1	+ 12 V DC
2	0 V
3	not connected



3-pole connector

10. GUARANTEE

LAMBDA provides a two-year guarantee on material and manufacturing defects, if the instrument was used according to the operation manual.

Conditions of guarantee:

- The instrument must be returned with a complete description of the defect or problem. In order to send back the equipment for repair, you will need a returns authorization number from LAMBDA.
- The customer will send the instrument to our service office.
- Damage or loss of items during transport will not be compensated for by LAMBDA.
- Failure to fulfill these requirements will disqualify the customer from compensation.

Serial Number:.....

Guarantee from:.....

LAMBDA Laboratory Instruments

Dr. Pavel Lehky
Imfeldsteig 12
CH-8037 Zurich, Switzerland
Tel/Fax: +41 444 50 20 71
info@lambda-instruments.com
www.lambda-instruments.com

LAMBDA CZ s.r.o.

Lozibky 1
CZ-614 00 Brno
Czech Republic
Tel/Fax: +420 545 578 643
Hotline: +420 603 274 677
www.peristaltic-pumps.eu